


## CONVENTIONAL GARAGE DOOR OPERATOR

## "UNIVERSAL" PRE-WIRING DIAGRAM



## PRE-WIRING FOR PHOTOELECTRIC SENSORS OR EDGE SENSORS

- 2 CONDUCTOR WIRE (22 GA) FROM LOCATION ① TO EXIT CEILING ABOVE OPERATOR.
- 2 CONDUCTOR WIRE (22 GA) FROM LOCATION @ TO EXIT CEILING ABOVE OPERATOR.

## PRE-WIRING FOR PUSHBUTTON

• 2 - CONDUCTOR WIRE (22 GA) FROM LOCATION ③ TO EXIT CEILING ABOVE OPERATOR.

2133 Frankfort Ave. • Louisville, KY 40206-2086 • (502) 897-5700 • Toll Free (877) 897-5700 • Fax (502) 897-5793 info@cunninghamdoor.com www.cunninghamdoor.com